



User Manual

**5KWH 10KWH 15KWH Wall Mounted
LiFePO4 Battery**

www.solarwaysuppliers.co.za

Content

Safety Precautions.....	2
Preface.....	3
1 Introduction.....	3
1.1 Brief Introduction.....	3
1.2 Product Properties.....	3
1.3 Product Identity Definition.....	4
2 Product Specification.....	5
2.1 Size and Weight	5
2.2 Performance Parameter	5
2.3 Interface Definition.....	6
2.3.1 DIP Switch Definition And Description	8
2.4 Battery Management System(BMS)	11
2.4.1 Voltage Protection	11
2.4.2 Current Protection	11
2.4.3 Temperature Protection	11
2.4.4 Other Protection	11
3 Installation and Configuration	12
3.1 Ready For Installation	12
3.1.1 Environmental Requirements	12
3.1.2 Tools And Data.....	12
3.1.3 Technical Preparation	13
3.1.4 Unpacking Inspection	13
3.1.5 Engineering coordination.....	14
3.2 Equipment Installation.....	14
3.2.1 Installation Preparation	14-16
4 Communicate inverter.....	17
4.1 Method 1:Communicate factory default inverters	17
4.2 Remark of inverter protocol code.....	17

Safety Precautions



Warning

- Please do not put the battery into water or fire, in case of explosion or any other situation that might endanger your life.
- Please connect wires properly while installation, do not reverse connect.
To avoid short circuit, please do not connect positive and negative poles with conductor (Wires for instance).
- Please do not stab, hit, trample or strike the battery in any other ways.
- Please shut off the power completely when removing the device or reconnecting wires during the daily use or it could cause the danger of electric shock.
- Please use dry powder extinguisher to put out the flame when encountering a fire hazard, liquid extinguisher could result in the risk of secondary disaster.
- For your safety, please do not arbitrarily dismantle any component in any circumstances unless a specialist or an authorized one from our company, device breakdown due to improper operation will not be covered under warranty.



Caution

- We have strict inspection to ensure the quality when products are shipped out, however, please contact us if case bulging or another abnormal phenomenon.
- For your safety, device shall be ground connected properly before normal use.
- To assure the proper use please make sure parameters among the relevant device are compatible.
- **Please do not mixed-use batteries from different manufacturers, different types and models, as well as old and new together.**
- Ambient and storage method could impact the life span and product reliability, please consider the operation environment abundantly to make sure device works in proper condition.
- **For long-term storage, the battery should be recharged once every 6 months, and the amount of electric charge shall exceed 80% of the rated capacity.**
- Please charge the battery in 18 hours after it discharges fully and starts over-discharging protection.
Formula of theoretical standby time: $T=C/I$ (T is standby time, C is battery capacity, I is total current of all loads).

Preface

Manual declaration

The Cyclone lithium iron phosphate battery energy storage system can provide energy storage solutions for photovoltaic power generation users through parallel combination. During the day, the excess power of photovoltaic power generation can be stored in the battery. At night or when needed, the stored electrical energy can be used to supply power to the electrical equipment, which can improve the efficiency of photovoltaic power generation, peak load shifting, and emergency power backup.

This user manual details the basic structure, parameters, basic procedures and methods of installation and operation and maintenance of the equipment.

1 Introduction

1.1 Brief Introduction


Cyclone lithium iron phosphate battery system is a standard battery system unit, customers can choose a certain number of batteries according to their needs, by connecting in parallel to form a larger capacity battery pack, to meet the user's long-term power supply needs. The product is especially suitable for applications with high operating temperatures, limited installation space, long power backup time and long service life.

1.2 Product Properties

Cyclone energy storage product's anode materials are lithium iron phosphate, battery cells are managed effectively by BMS with better performance, the system's features as below:

- Comply with European ROHS, Certified SGS, employ non-toxic, non-pollution environment-friendly battery.
- Anode materials are lithium iron phosphate (LiFePO₄), safer with longer life span.
- Carries battery management system with better performance, possesses protection function like over-discharge, over-charge, over-current, abnormal temperature.
- Self-management on charging and discharging, Single core balancing function.
- Flexible configurations allow parallel of multi battery for longer standby time.
- Self-ventilation with lower system noise.
- Less battery self-discharge, then recharging period can be up to 6 months during the storage.
- No memory effect so that battery can be charged and discharged shallowly.
- With wide range of temperature for working environment, -20°C ~ +65 °C, circulation span and discharging performance are well under high temperature.
- Less volume, lighter weight.

1.3 Product identity definition

	Be careful with your actions and be aware of the dangers.
	Read the user manual before using.
	The scrapped battery cannot be put into the garbage can and must be professionally recycled.
	After the battery life is terminated, the battery can continue to be used after it recycled by the professional recycling organization and do not discard it at will.
	This battery product meets European directive requirements.
	Battery voltage is higher than safe voltage, direct contact with electric shock hazard.
DANGER HIGH VOLTAGE INSIDE  * Do not disassemble, disassemble or repair by yourself. * Do not drop, deform, impact, cut or squeezing with a sharp object. * Do not place near open flames or incinerator. * Do not call or put heavy things on battery. * Keep away from moisture or liquid. * Keep away from children, animals or insects. * Contact the supplier within 24 hours if anything wrong. Emergency Situations * Shorting, fire, over-temperature, switch off the breaker and go away from the battery. * Do not touch the leaking liquid. Do not use water, sand or dry powder extinguisher is suitable.	

2 Product Specification

2.1 Size and Weight

Table 2-1 Device size

Product	Nominal Voltage	Nominal Capacity	Dimension	Weight
Cyclone F5	DC51.2V	100Ah	480x600x165mm	≈52kg
Cyclone F10	DC51.2V	200Ah	480x650x245mm	≈92kg
Cyclone F15	DC51.2V	280Ah	490x830x250mm	≈135kg

2.2 Performance Parameter


Table 2-2 performance parameter

Item	Parameter value	Parameter value	Parameter value
Nominal Voltage(V)	51.2	51.2	51.2
Work Voltage Range(V)	44.8~56.8	44.8~56.8	44.8~56.8
Nominal Capacity(Ah)	100	200	280
Nominal Energy(kWh)	5.12	10.24	14.34
Charge Voltage(V)	55.2~56.8	55.2~56.8	55.2~56.8
Discharge Cutoff Voltage(V)	44.8	44.8	44.8
Charge Cut Off Voltage(V)	56.8	56.8	56.8
Max. Continuous Charging Current(A)	100	150	150
Max. Continuous Discharging Current(A)	100	150	150


2.3 Interface Definition

This section elaborates on interface functions of the front interface of the device.


Cyclone F5



Cyclone F10



Cyclone F15



Item	Name	Definition
1	Power switch	OFF/ON, must be in the "ON" state when in use
2	DRY CONTACT	/
3	ADDR	DIP switch
4	RS485	Communication cascade port, support RS485 communication
5	CAN	Communication cascade port, support CAN communication (factory default CAN communication)
6	USB	Communication cascade port, battery connect to the host computer
7	Parallel 1 (RS485) Parallel 2 (RS485)	Battery parallel connection ports
8	Positive Socket	Battery output positive or parallel positive line
9	Negative Socket	Battery output negative or parallel negative line
10	Ground Terminal	Grounding device
11	Circuit Breaker	OFF/ON, must be in the "ON" state when in use


2.3.1 DIP switch definition and description

Table 2-4 Interface Definition

DIP switch position (host communication protocol and baud rate selection)			
#1	#2	#3	#4
Baud rate			
CAN: 500K, 485: 9600			

DIP switch description:


When the battery pack is connected in parallel, the host can communicate with the slave through the RS485 interface. The host summarizes the information of the entire battery system and communicates with the inverter through CAN or 485. The connection mode is divided into the following two cases:



Pack	Codes the switch position			
	#1	#2	#3	#4
1	OFF	OFF	OFF	OFF
2	ON	OFF	OFF	OFF
3	OFF	ON	OFF	OFF
4	ON	ON	OFF	OFF
5	OFF	OFF	ON	OFF
6	ON	OFF	ON	OFF
7	OFF	ON	ON	OFF
8	ON	ON	ON	OFF
9	OFF	OFF	OFF	ON
10	ON	OFF	OFF	ON
11	OFF	ON	OFF	ON
12	ON	ON	OFF	ON
13	OFF	OFF	ON	ON
14	ON	OFF	ON	ON
15	OFF	ON	ON	ON
16	ON	ON	ON	ON

Table 5 Dial switch position

Table 2-4 Pin Definition
RS485-1 / CAN Communication Interface Definition:



Interface	Defined declaration		Defined declaration			
X1 Communication port definition	A part CAN joggle	PIN 1	NC(empty)	B part RS-485-1 Interface	PIN 1	RS485-B1
		PIN 2	CGND		PIN 2	RS485-A1
		PIN 3	NC(empty)		PIN 3	RS485-GND
		PIN 4	CANH		PIN 4	RS485-B1
		PIN 5	CANL		PIN 5	RS485-A1
		PIN 6	NC(empty)		PIN 6	RS485-GND
		PIN 7	CGND		PIN 7	NC(empty)
		PIN 8	NC(empty)		PIN 8	NC(empty)

Table 7 The RS 485-1 / CAN port definition

LED status indicators for wall mounted battery

State	Normal/Alarm/Protection	The power level indicates the LED				Remark
		25% 	50% 	75% 	100% 	
Shutdown	Dormancy	Off	Off	Off	Off	
Standby	Normal	According to the electricity instruction				
	Alarm	Red flash	According to the electricity instruction			
Charge	Normal	According to the electricity instruction				
	Alarm	Red flash	According to the electricity instruction			
	Total voltage overcharge protection	Red flash	Lighting	Lighting	Lighting	Stop charging
	Single cell voltage overcharge protection	Red flash	Lighting	Lighting	Lighting	Stop charging
	Temperature protection	Red flash	Flash 2	Off	Off	Stop charging
	Overcurrent protection	Red flash	Off	Flash 2	Flash 2	Stop charging
Discharge	Normal	According to the electricity instruction				
	Alarm	Red flash	According to the electricity instruction			
	Total voltage overdischarge protection	Red flash	Off	Off	Off	Stop discharging
	Single cell voltage overdischarge protection	Red flash	Off	Off	Off	Stop discharging
	Temperature protection	Red flash	According to the electricity instruction			Stop discharging
	Overcurrent protection	Red flash	According to the electricity instruction			Stop discharging
Lose efficacy	Battery failure	Red flash	According to the electricity instruction			Stop charging and discharging
	Charge and discharge MOS failure	Red flash	Off	Off	Off	Stop charging and discharging
	AFE failure	Red flash	Off	Off	Off	Stop charging and discharging
	Current Sense Resistor Failure	Red flash	Off	Off	Off	Stop charging and discharging
	Voltage failure	Red flash	Off	Off	Off	Stop charging and discharging
	Reverse connection failure	Red flash	Off	Off	Off	Stop charging and discharging
	Short circuit	Red flash	Off	Off	Off	Stop charging and discharging

LED working status indication

The state		Charge				Discharge			
Capacity indicator light		L4	L3	L2	L1	L4	L3	L2	L1
electricity(%)	0~25%	off	off	off	Flash, 2	off	off	off	Lighting
	25~50%	off	off	Flash, 2	Lighting	off	off	Lighting	Lighting
	50~75%	off	Flash, 2	Lighting	Lighting	off	Lighting	Lighting	Lighting
	75~100%	Flash, 2	Lighting	Lighting	Lighting	Lighting	Lighting	Lighting	Lighting

LED flashing instructions

Flash Mode	Lighting	OFF
Flash1	0.25S	3.75S
Flash2	0.5S	0.5S
Flash3	0.5S	1.5S

2.4 Battery Management System(BMS)

2.4.1 Voltage Protection

Discharging Low Voltage Protection :

When any battery cell voltage is lower than the protection value during discharging, the over-discharging protection starts, and the battery buzzer makes an alarm sound. Then battery system stops supplying power to the outside. When the voltage of each cell recovers to rated return range, the protection is over.

Charging Over Voltage Protection :

When total voltage or any battery cell voltage reaches the protection value during charging, battery stops charging. When total voltage or a cell recover to rated return range, the protection is over.

2.4.2 Current Protection

Over Current Protection in Charging :

When the charging current is greater than the protection value, the battery buzzer alarms and the system stops charging. Protection is removed after rated time delaying.

Over Current Protection in Discharging :

When the discharge current is greater than the protection value, the battery buzzer alarms and the system stops discharging. Protection is released after rated time delaying.



Note:

The buzzer sound alarm setting can be manually turned off on the background software, and the factory default is on.

2.4.3 Temperature Protection

Less/Over temperature protection in charging :

When battery's temperature is beyond range of 0 °C ~+65 °C during charging, temperature protection starts, device stops charging.
The protection is over when it recovers to rated return range.

Less/Over temperature protection in discharging :

When battery's temperature is beyond range of -20 °C ~+45 °C during discharging, temperature protection starts, device stops supplying power to the outside.

2.4.4 Other Protection

Short Circuit Protection :

When the battery is activated from the shutdown state, if a short circuit occurs, the system starts short-circuit protection for 30 seconds.

Self-Shutdown :

When device connects no external loads and power supply and no external communication for over 72 hours, device will dormant standby automatically.



Caution

Battery's maximum discharging current should be more than load's maximum working current.

3 Installation and Configuration

3.1 Ready for installation

Safety Requirement

This system can only be installed by personnel who have been trained in the power supply system and have sufficient knowledge of the power system.

The safety regulations and local safety regulations listed below should always be followed during the installation.

- All circuits connected to this power system with an external voltage of less than 48V must meet the SELV requirements defined in the IEC60950 standard.
- If operating within the power system cabinet, make sure the power system is not charged. Battery devices should also be switched off.
- Distribution cable wiring should be reasonable and has the protective measures to avoid touching these cables while operating power equipment.
- when installing the battery system, must wear the protective items below:



The isolation gloves



Safety goggles



Safety shoes

Figure3-1

3.1.1 Environmental requirements

Charging temperature range is 0 °C ~+45°C

Discharging temperature range is -20 °C ~+65°C

Storage temperature: -20 °C ~ +45 °C

Relative humidity: 5% ~ 85%RH

Elevation: no more than 4000m

Operating environment: Indoor installation, sites avoid the sun and no wind, no conductive dust and corrosive gas.

Meet the following situations:

- Installation location should be away from the sea to avoid brine and high humidity environment.
- The ground is flat and level.
- There is no flammable explosive near to the installation places.
- The optimal ambient temperature is 15 °C ~ 30 °C
- Keep away from dust and messy zones

3.1.2 Tools and data

Hardware tool

Tools and meters that may be used are shown in table 3-1.

Table 3-1 Tool instrument

Name	
Screwdriver (word, cross)	AVO meter
Wrench	Clamp meter
Inclined pliers	Insulating tape
Needle nose pliers	The thermometer

Name	
Clip forceps	Wrist strap
Wire stripper	AVO meter
Electric drill	Tape

3.1.3 Technical preparation

Electrical interface check

Devices that can be connected directly to the battery can be user equipment, power supplies, or other power supplies.

- Confirm whether the user's PV power generation equipment, power supply or other power supply equipment has a DC output interface, and measure whether the DC power output voltage meets the voltage range requirements in Table 2-2.
- Confirm that the maximum discharge current capability of the DC power interface of the user's photovoltaic power generation equipment, power supply or other power supply equipment should be greater than the maximum charging current of the products used in Table 2-2.

If the maximum discharge capacity of the DC power interface of the user's photovoltaic power generation equipment is less than the maximum charging current of the products used in Table 2-2, the DC power interface of the user's photovoltaic power generation equipment shall have a current limiting function to ensure the normal operation of the user's equipment.

- Verify that the maximum operating current of the battery-powered user equipment (inverter DC input) should be less than the maximum discharge current of the products used in Table 2-2.

The security check

- Firesuppression equipment should be provided near the equipment, such as portable dry powder fire extinguisher.
- Automatic fire suppression system shall be provided for the case where necessary.
- No flammable, explosive and other dangerous articles are placed beside the battery.

3.1.4 Unpacking inspection

- When the equipment arrives at the installation site, loading and unloading should be carried out according to the rules and regulations, to prevent from being exposed to sun and rain.
- Before unpacking, the total number of packages shall be indicated according to the shipping list attached to each package, and the case shall be checked for good condition.
- In the process of unpacking, handle with care and protect the surface coating of the object.
- Open the package, the installation personnel should read the technical documents, verify the list, according to the configuration table and packing list, ensure objects are complete and intact, if the internal packing is damaged, should be examined and recorded in detail.

3.1.5 Engineering coordination

Attention should be paid to the following items before construction:

- Power line specification.
The power line specification shall meet the requirements of maximum discharge current for each product.
- Mounting space and bearing capacity.
Make sure that the battery has enough room to install, and that the battery rack and bracket have enough load capacity.
- Wiring.
Make sure the power line and ground wire are reasonable. Not easy to short-circuit, water and corrosion.



3.2 Equipment installation

3.2.1 Installation steps

Table 3-2 Installation steps

Step1	Installation preparation	Confirm that the ON/OFF switch on the front panel of unit is in the "OFF" state to ensure no live operation.
Step 2	Mechanical installation	1. Battery placement position determination
		2. Cable harness pre-installed
		3. Battery module installation
Step3	Electrical installation	1. Ground cable installation
		2. Battery module parallel cable installation
		3. Battery module total positive cable installation
		4. Battery module total negative cable installation
		5. Internal CAN communication interface connection
Step4	Battery system self-test	1. Press the ON/OFF switch to the "ON" state
		2. BMS system power-on activation
		3. Check the system output voltage
		4. Shut down the system
Step5	Connecting inverter	1. Connect total positive & total negative cable of the battery system to the inverter
		2. Connect the external CAN/RS485 communication cable to the inverter(Details as page 15)

Product Diagram :




Accessories:(Optional)



Parallel Connection Of Batteries

The circulation connection method can effectively alleviate the voltage difference between the parallel batteries. As shown in the figure below:



Connection between battery and inverter:

Connect the positive pole and positive pole in parallel(in red color), the negative pole and negative pole in parallel(in black color),with power line.

Connect the RS485/CAN port from the battery and the RS485/CAN port from the inverter, with the cable.

Connection between batteries:

Connect the positive pole and positive pole in parallel(in red color), the negative pole and negative pole in parallel(in black color), with power line.

Connect the RS485 port from the battery and the RS485 port from the other battery , with the cable.

Installation Notes:

1. As shown in the figure below, press the fixed pendant on the wall surface with one hand, use a marker to draw the installation positioning hole of the fixed pendant, and use a tool to drill.




2. As shown in the figure below, fix the attached 4 M8 expansion bolts in the opening of the pendant, and tighten the nuts on the bolts.



3. Lift up the 51.2V battery box, adjust the opening of the pendant on the back of the box to align with the pendant on the wall as shown in the figure below, and then use a marker to mark the mounting bracket of the box, and use tools to drill holes for the mounting bracket.

Wall Mounted



4 Communicate inverter

4.1 Method 1: Communicate factory default inverters

Step 1: Select the cables used by the inverter by the label on the communication cables. Insert the RJ45 connector of the battery end (CAN/RS485) and the inverter end (CAN/RS485) into the interfaces on both sides.

Step 2: Turn on the battery and inverter and wait until they are working properly. The battery is configured by factory default to communicate with the Voltronics, Mecer, Kodak, Phocos, Axpert Inverter (RS485 Port), DEYE Sunsynk, SMK (Hybrid), Luxpower, Sofar, TBB inverters (CAN Port), the battery will automatically select and communicate with one of these inverters.

4.2 Remark of inverter protocol code

RS485 Communication Protocol		
Protocol abbreviation	Protocol Name	Compatible with Inverter brands
Local	Local Protocol	
Voltronic	Voltronic Protocol	MOTOMA/Opti_Solar/Darfon/Phocos
Growatt	Growatt protocol	Sunk/Sacolar/SMK
SOLAX	SOLAX Protocol	
LTW	LTW Protocol	
PACE	PACE Protocol	
MUST	MUST Protocol	
SRNE	SRNE Protocol	PC
Baykee	Baykee Protocol	
SMK	SMK Protocol	
AFORRE	AFORRE Protocol	
GENIXGREEN	GENIXGREEN Protocol	
BITTA	BITTA	
STONE	STONE	
PYLONTECH	PYLONTECH Protocol	
EPEVER	EPEVER Protocol	

CAN Communication Protocol		
Protocol abbreviation	Protocol Name	Compatible with Inverter brands
Local	Local Protocol	
GOODWE	GOODWE Protocol	SOLARFAM
Growatt	Growatt Protocol	
SOLAX	Solax Protocol	
Sofar	Sofar Protocol	
DEYE	DEYE Protocol	
MUST	MUST Protocol	
LTW	LTW Protocol	
Victron	Victron Protocol	
PYLONTECH	PYLONTECH Protocol	DEYE/TBB/Luxpower/INVT/Sunsynk/Megarevo/CHINT/LIVOLTEK/Hoymiles
SOROTEC	SOROTEC Protocol	
Afore	Afore Protocol	
SCHNEIDER	SCHNEIDER Protocol	
GENIXGREEN	GENIXGREEN Protocol	
Inhenergy	Inhenergy Protocol	
SMA	SMA Protocol	Sorotec/Studer
Solis	Solis Protocol	
DONEERGY	DONEERGY Protocol	
SENERGY	SENERGY Protocol	
SUNWAYS	SUNWAYS Protocol	
Studer	Studer Protocol	
INVT	INVT Protocol	



facebook



Instagram



Twitter



Solarway Suppliers



Cyclone Lithium power